

Items for Yamaha - Tenere 700 Explore

TARYA136B3 Adjustable LTARYA136B2TARYA136B1TARYA136A3	icense Plate Holder			
• TARYA136A2 • TARYA136A1			NeroB3NeroB2NeroB1NeroA3NeroA2NeroA1	€ 105,00
• Adjustable L KTARYA136B3 • KTARYA136B1 • KTARYA136A3 • KTARYA136A2 • KTARYA136A1	icense Plate Holder Kit		• NeroB3 • NeroB1 • NeroA3 • NeroA2 • NeroA1	€ 135,00
• FRE929NER Indicators (P Led Turn Sig		Sollos	• Black	€ 48,00
• FRE926NER Indicators (P Led Turn Sig			• Black	€ 43,50



• FRE922NER Indicators (Pair Of Homologated E8 Led Turn Signals)

• Black

€ 43,50



• FRE936NER Indicators (Pair Of Homologated E8 Led Turn Signals)

• Black

€ 39,50



• FRE932NER Indicators (Pair Of Homologated E8 Led Turn Signals)

Black

€ 52,00





• FRE930ROS Indicators (Pair Of Homologated E8

• FRE930COB Led Turn Signals)

RedCobalt

€ 58,00



• STK120 Lateral Reflector Kit (Homologated F)

• Gold

€ 8,00



• FRE925NER Sequential Indicators (Pair Of Homologated E8 Led Turn Signals)

Black

€ 48,00





• FRE937NER turn signals + front white light (
Homologated E... Led Turn Signals)

• Black

€ 44,00



• FRE934NER turn signals + front white light (
Homologated E... Led Turn Signals)

• Black

€ 52,80



• FRE935NER Turn signals + rear red light + stop light (Pair Of Homologated E... Led Turn Signals)

Black

€ 52,80



• FRE938NER Turn signals + rear red light + stop light (Pair Of Homologated E8 Led Turn Signals)

Black

€ 44,00

